



INSTRUCTION MANUAL

EW6140

AQUAROVER 140 1800W 140 Bar Corded Pressure Washer

Ewbank has a British heritage to be proud of. It's a household favourite and much loved brand that has been providing innovative cleaning solutions for over 140 years.



Safety Instructions 3 - 11
Appliance Overview 12
Product Assembly 13 - 14
Operating Instructions 15 - 19
Cleaning & Maintenance 20
Troubleshooting 21
Specifications 22
Fuse Replacement 23
Disposal of the Appliance 23
Warranty Terms & Conditions 24

SAVE THESE INSTRUCTIONS

PLEASE READ ALL THE INSTRUCTIONS BEFORE USE AND STORE THEM IN A SAFE PLACE FOR FUTURE REFERENCE. WARNINGS AND NOTES THAT ARE AFFIXED TO THE APPLIANCE PROVIDE IMPORTANT NOTES FOR SAFE OPERATION AND MUST BE FOLLOWED.

HAZARD LEVELS GUIDE

There are important notes throughout the safety instructions and instruction manual that outline potential hazards when the appliance is use which range in severity. Please see below guide to these hazard levels to be aware of when reading through the instruction manual:



DANGER

This indicates an immediate danger, which if not avoided could lead to serious injury or death



WARNING

This indicates a potentially dangerous situation, which if not avoided could lead to serious injury or death



CAUTION

This indicates a potentially dangerous situation, which if not avoided could lead to minor injury

ATTENTION

This indicates a potentially dangerous situation, which if not avoided could lead to damage to the appliance and/or property

WHEN USING THE APPLIANCE, THE FOLLOWING PRECAUTIONS MUST BE TAKEN: ELECTRICAL COMPONENTS



DANGER

- Risk of electric shock
- Never touch the mains plug and the socket with wet hands
- Check the power cord and mains plug for damage prior to every use
- Do not use the machine if the power cord, mains plug or other important parts of the machine are damaged or appear damaged e.g. safety devices, high pressure hoses, high-pressure gun etc.
- All electrical components within the area being cleaned must be protected against jet water
- The mains plug and extension cable (if being used) must be watertight and must never lie in water - the use of cable reels that ensure that the sockets are at least 60 mm above the ground is recommended
- Make sure that the power cord or extension cable is not damaged by running over, pinching, dragging etc.
- Protect the power cords from heat, oil, and sharp edges or objects
- Always switch off the power at the mains plug switch when leaving the appliance unattended



WARNING

- The appliance may only be connected to an electric supply that has been installed by an electrician in accordance with IEC 60364
- The appliance may only be connected to alternate current and the voltage must correspond with the rating label affixed to the appliance

- For safety reasons, we recommend that you operate the appliance only via a residual current device (max. 30mA)
- An unsuitable electrical extension cable can be hazardous - only use an electrical extension cable which has been approved and labeled for this purpose and has an adequate cable cross-section outdoors: 1 - 10 m: 1.5 mm²; 10 - 30 m: 2.5 mm²
- Always fully unreel the extension cable from the cable drum

OPERATION



DANGER

- Please only operate the appliance as it is intended to be used - the operator must consider the surrounding conditions and must pay attention to other people in the vicinity when working with the appliance
- Check important components, such as high-pressure hose, hand spray gun and safety installations, for damage prior to every operation - immediately replace damaged components and do not operate appliance
- The appliance has been designed for use with the cleaning agent supplied or recommended by the manufacturer - the use of the other cleaning agents or chemicals may adversely affect the safety of the appliance
- High-pressure jets can be dangerous if subject to misuse - the jet must not be directed at persons or animals, live electrical equipment or the machine itself
- Do not direct the jet against yourself or others to clean clothes or foot-wear



WARNING

- Do not use the appliance within range of persons unless they wear protective clothing
- It is recommended to wear appropriate Personnel Protection Equipment (PPE) while operating the appliance

- The appliance must not be operated by children or untrained personnel
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capacities, or lacking experience and knowledge
- Children must not play with this appliance
- Supervise children to prevent them from playing with the appliance
- Create stability for the appliance prior to any work on or with the appliance to prevent accidents damage
- The water jet that is emitted from the high-pressure nozzle, could result in a repulsion power action on the hand spray gun - make sure that you have a firm footing and are also holding the hand spray gun and spray lance firmly
- Never leave the appliance unattended if it is in operation

 **CAUTION**

- Be aware of kick-back when using the appliance – always hold with both hands

 **ATTENTION**

- In case of extended breaks in usage, switch the appliance off at the main switch or pull the mains plug
- Do not operate the appliance at temperatures below 0°C

OTHER RISKS

 **DANGER**

- The appliance must not be operated in explosive environments
- Risk of explosion - do not spray flammable liquids
- Never draw in fluids containing solvents or undiluted acids and solvents - this includes petrol, paint thinner and heating oil where the spray mist is highly inflammable, explosive and poisonous
- Do not use acetone, undiluted acids and solvents, as they corrode the materials used on the appliance

- Never use the product with inflammable or toxic liquids, or liquids with characteristics incompatible with its proper operation
- Keep packaging films away from children as there is a risk of suffocation



WARNING

- According to the applicable regulations, the appliance may never be used with the drinking water network without a system separator; ensure that the connection to your house water system, with which the high-pressure cleaner is operated, is equipped with a system separator according to EN 12729 type BA
- Water that has flowed through a system separator is no longer classified as drinkable
- High-pressure hoses, fittings and connections are important for the safety of the appliance; only use high-pressure hoses, fittings and couplings recommended by the manufacturer
- Only use original spare parts from the manufacturer or that are approved by the manufacturer
- Switch the appliance off and disconnect it from the power supply by removing the mains plug from the socket outlet before assembly, cleaning, adjustments, maintenance, storage and transportation
- The improper use of detergents can cause severe injuries or oxidation
- Store cleaning agents away from the reach of children
- Discharge any residual pressure before disconnecting the hose from the appliance
- Check before each use of the appliance, that all metal fasteners are tight, and the products components are in good condition; inspect for broken or worn parts



CAUTION

- Check the weight of the appliance when selecting the storage location and during transport to prevent accidents or injuries

- Several hours of continuous use of the appliance can lead to numbness in the hands in rare cases; we recommend you:
 - Wear gloves when operating the appliance
 - Keep hands warm
 - Take regular breaks

SERVICING OF DOUBLE-INSULATED APPLIANCE

In a double-insulated product, two systems of insulation are provided instead of grounding. Grounding means are not provided for a double-insulated product, nor should grounding means be added to the product. Servicing a double-insulated product requires extreme care and knowledge of the system and should only be done by qualified service personnel. Replacement parts for a double-insulated product must be identical to the original parts. A double-insulated product is marked with the words "Double Insulation" or "Double Insulated", and is indicated by the following symbol which will be visible on the rating label affixed to the appliance:



RESIDUAL RISKS

Even if you are operating this product in accordance with all the safety requirements, potential risks of injury and damage remain. The following dangers can arise in connection with the structure and design of this product:

- Health defects resulting from vibration emission if the product is being used over long periods of time or not adequately managed and properly maintained
- Danger of injury and property damage caused by flying objects
- Injuries and damage to property due to broken accessories or the sudden impact of hidden objects during use

SAFETY DEVICES

CAUTION

Safety devices have been installed on the device to provide protection to the user and may not be modified or bypassed.

- **POWER SWITCH**
 - The appliance switch prevents unintentional operation of the appliance
- **GUN TRIGGER LOCK**
 - This locks the trigger on the gun to prevent the inadvertent starting of the appliance
- **AUTO STOP SYSTEM**
 - If the lever on the gun trigger is released the auto stop system turns off the pump AND the high-pressure jet is stopped
 - If the lever is pulled the pump is turned on again
- **MOTOR PROTECTION SWITCH**
 - The motor protection switches off the device if the power consumption is too high
- **PERSONAL PROTECTIVE EQUIPMENT**

CAUTION

- Wear protective clothing and safety goggles to protect against splash back containing water or dirt
- During use the pressure washer can develop aerosols which can potentially cause health issues
- Depending on the application, completely shielded nozzles (e.g. surface cleaner) that significantly reduce the emission of aqueous aerosols can be used for high-pressure cleaning
- The use of such shielding is not possible with all applications

- **SYMBOLS ON THE MACHINE**



The high-pressure jet must not be directed at persons, animals, live electrical equipment or at the appliance itself



The appliance must not be directly connected to the public drinking water network



For protection against injury, wear ear defenders and safety goggles



Wear safety gloves during use to protect hands




Wear non-slip footwear that will protect your feet and improve your footing on slippery surfaces



Sound power level is 92dB(A)


PROPER USE

- Use this pressure washer for private households only
- This high-pressure cleaner is designated with a rated input current
- The intended use of this product covers the cleaning of vehicles, buildings, terraces, facades and garden equipment using clean water and biodegradable chemical detergents, paving slabs or rain gutters
- This product may not be used to clean clothing, shoes and other textiles
- The water jet should not be directed at people, animals, any electrical equipment or at the product itself
- Do not flush any objects which contain health hazardous materials
- The product must not be run with inflammable, explosive and toxic liquids
- For safety reasons it is essential to read the entire instruction manual before first operation and to observe all the instructions inside




- | | |
|-----------------------------|---|
| 1. Handle | 10. Self-suction valve |
| 2. Spray lance | 11. High-pressure gun |
| 3. Water inlet | 12. High-pressure gun holder |
| 4. Spray lance holder | 13. Jet nozzle |
| 5. High-pressure hose hook | 14. Adjustable fan nozzle and angled spray nozzle |
| 6. High-pressure hose | 15. Rear wheels |
| 7. Power switch OFF/ON | 16. Detergent bottle |
| 8. Handle | 17. Power cord |
| 9. Front wheels with brakes | |

ACCESSORIES



- | |
|--------------------------|
| 1. Spray lance |
| 2. High-Pressure gun |
| 3. Detergent bottle |
| 4. Angled spray nozzle |
| 5. Jet nozzle |
| 6. Adjustable fan nozzle |
| 7. Patio brush |
| 8. Fixed brush |





CAUTION

Ensure that the appliance is fully and correctly assembled before use.

1. Installing the handle with screws

- Insert/line up the handle as shown in Fig.1
- Ensuring each hole aligns with the screws provided, insert and fasten tightly to secure




Fig.1

2. Installing the spray lance

- Fit the spray lance into the high-pressure gun and rotate it until the two parts are completely locked (Fig.2)
- Push the desired nozzle onto the quick connect collar of the spray lance until it clicks into place (Fig.2)




Fig.2

3. Connect the high-pressure hose to the high-pressure gun

- Connect the silver end of the high-pressure hose to the high-pressure gun and twist the nut to secure the connection (Fig.3)




Fig.3

4. Connect the high-pressure hose to the water outlet

- Connect the other end of the high-pressure hose to the water outlet on the pressure washer and twist the black rotatable end-piece as indicated to secure the connection (Fig.4)




Fig.4

5. Connect the garden hose to the water inlet

- Connect the garden hose adaptor (female coupler) to the water inlet of the pressure washer, then thread your garden hose (male end) into the garden hose adaptor (Fig.5)




Fig.5

APPLIANCE START UP


1. Park the appliance on an even surface
2. Insert the mains plug into the socket

Water supply

For connection values, see type plate.

ATTENTION

Impurities in the water can damage the high-pressure pump and the accessories.



3. Attach garden hose to water supply

CAUTION

- o Do not connect to potable water system
 - o The water supply must not exceed 0.7MPa
 - o The washer must only be used with clean water, use of unfiltered water containing corrosive chemicals will damage the pressure washer
4. Bleed the device as follows prior to operation:
 - i) Turn on the appliance "OFF/ON"
 - ii) Unlock the lever of the high-pressure gun
 - iii) Push the lever of the high-pressure gun, the device will switch on
 - iv) Let the device run (max. 2 minutes) until the water exits the high-pressure gun without bubbles
 - v) Release the lever of the high-pressure gun
 - vi) Lock the lever of the high-pressure gun

ATTENTION

Dry running of more than 2 minutes leads to damage of the high-pressure pump. If the appliance does not build up pressure within 2 minutes, switch the appliance off and proceed in accordance with the instructions in the "Troubleshooting" section of the instruction manual

HIGH PRESSURE OPERATION**CAUTION**

Keep a distance of at least 30 cm when using the jet for cleaning painted surfaces to avoid damage.


**CAUTION**

Make sure the power switch is set to "OFF" before inserting the plug into a properly installed socket.

ATTENTION

- The washer must be used on a secure and stable surface
1. Connect the product to power and water supply as described.
 - i. Open the water supply
 - ii. Hold the high-pressure gun with both hands
 - iii. Direct the nozzle of the chosen accessory away from you towards the surface to be cleaned
 - iv. Unlock the trigger and press it until a constant amount of water flows through the nozzle, to allow air trapped in the hose to escape
 - v. Release the trigger
 - vi. Turn the power switch from "OFF" to "ON"
 - vii. Hold the spray gun with both hands. Direct the water jet to the object to be cleaned and press the trigger
 - viii. Release the lever of the high-pressure gun; the device will switch off again and stop the water jet. High pressure remains in the system


WARNING! Beware of kickback when pressing the trigger!



DETERGENT OPERATION

ATTENTION

Detergent can only be added when the device is operated in low pressure mode. Like below pic. Only gun and lance can be used.



DANGER

When using detergents, the material data safety sheet issued by the detergent manufacturer must be adhered to, especially the instructions regarding personal protective equipment.

Remove the cap of the clean detergent bottle. Gently pull the onboard detergent tank out of its storage position.

Fill the tank with detergent designed specifically for use with pressure washers.

Push the detergent bottle with the opening pointing downwards into the connection for the hose clean detergent.

Note: Detergent will not work on jet nozzle

RECOMMENDED CLEANING TECHNIQUE

- Spray the detergent sparingly on the dry surface and allow it to react, but not to dry
- Spray off loosened dirt with the high-pressure jet

AFTER OPERATION WITH DETERGENT

- Remove the hose clean detergent bottle from the intake and close it with the lid
- For storage, put the detergent bottle into the retainer with the cap pointing up

INTERRUPTING OPERATION

- Release the lever of the high-pressure gun
- Lock the lever of the high-pressure gun
- Put the high-pressure gun with the spray lance into the parking position
- Switch the device off "0/OFF" during work breaks longer than 5 minutes

OPERATION WITH ATTACHMENTS

ATTENTION

Your AQUAROVER 140 comes with certain accessories. Only use original accessories and original spare parts for this model. They ensure that the appliance will run fault-free and safely.

ASSEMBLING PATIO BRUSH

Thread the patio brush connector into the larger hole on top of the brush head (fig 6). On the underside push the rotating spray arm in and screw into place (fig 7).



Fig.6



Fig.7

With chosen nozzle or brush line the opening together with the lance. Push in to place and twist to secure (fig 8).



Fig.8

ENDING OPERATION



CAUTION

Pressure in the system

Injuries from high-pressure water escaping uncontrollably.

Only disconnect the high-pressure hose from the high-pressure gun or the device when the system is fully depressurised.

- Release the lever of the high-pressure gun
- Turn the power switch to "OFF"
- Disconnect the mains plug from the socket

Only separate the high-pressure hose from the high-pressure gun or the device when there is no pressure in the system

TURN OFF TAP

- Press the lever of the high-pressure gun to release any remaining pressure in the system
- Release the lever of the high-pressure gun
- Lock the lever of the high-pressure gun

ATTENTION

- When disconnecting the supply or high-pressure hose, warm water may leak from the connection after operation
- Detach the appliance from the water supply

TRANSPORTATION**CAUTION**

Risk of personal injury or damage!
Mind the weight of the appliance during transport.

Transporting by hand

- Switch the product off and disconnect it from the water and power supply
- Pull out the transport handle until it audibly clicks into place. Attach transportation guards, if applicable
- Pull the appliance by its transport handle

Transporting in vehicles

- Prior to horizontal transport: close the cap of clean detergent bottle
- Tilt the product towards you until it balances on the wheels. Then move it by its transportation handle
- Protect the product from any heavy impact or strong vibrations which may occur during transportation in vehicles
- Secure the appliance against shifting and tipping over

STORAGE**CAUTION**

Risk of personal injury or damage!
Consider the weight of the appliance when storing it.

STORING THE APPLIANCE

- Park the machine on an even surface
- Detach spray lance from the high-pressure gun
- Push the disconnect button on the high-pressure gun and pull the high-pressure hose out of the high-pressure gun
- Place the high-pressure gun into the storage part for the high-pressure gun
- Put both spray lances into the storage part for the spray lance
- Dirt grinder spray lance: Nozzle towards the bottom
- Coil the high-pressure hose and hang it over the hose storage
- Store the mains connection in the accessory compartment
- Prior to extended storage periods (such as during winter months) also observe the instructions in the care section
- Always store the pressure cleaner, parts, and accessories in a place that is inaccessible to children
- The ideal storage temperature is between 10 °C and 30 °C

- Store the power washer indoors to prevent the water in the unit from expanding under freezing conditions
- We recommend using the original package for storage or covering the product with a suitable cloth or enclosure to protect it against dust

FROST PROTECTION

ATTENTION

Appliance and accessories that are not completely drained can be destroyed by frost.


Completely drain appliance and accessories and protect them against frost. To avoid damage:

- Detach the appliance from the water supply
- Detach spray lance from the high-pressure gun
- Turn on the appliance "ON/OFF"
- Push the lever of the high-pressure gun until no more water is escaping
- Release the lever of the high-pressure gun
- Lock the lever of the high-pressure gun
- Turn off the appliance "ON/OFF"
- Store the appliance and the entire accessories in a frost-free room

CARE AND MAINTENANCE**DANGER**

Risk of electric shock

Prior to all work on the appliance, switch off the appliance and pull the power plug.

High pressure hose

The high-pressure hose is specially constructed with reinforced walls it can be easily damaged and should be stored carefully.

- Do not kink
- Do not drive vehicles over the hose
- Do not expose the hose to sharp edges or corners. Misuse will lead to ballooning or premature failure and will invalidate warranty

Nozzle


- To disconnect a nozzle from the spray wand once the cleaning job is complete
- Do not expose the nozzle in corrosive liquid

Filter in the water connection**ATTENTION**

- The filter must not be damaged
- Pull the filter out using flat pliers
- Clean the filter under running water
- Reinsert the filter into the water connection

Clean the filter in the water connection regularly.

- Remove coupling from the water connection, and rinse with warm water to prevent any foreign matter from clogging the pump
- Clean the nozzle with the needle clean-out tool provided
- Remove the spray wand from the gun
- Remove any dirt from the nozzle hole and rinse



If you experience difficulties with the appliance, please check the suggestions below before contacting customer services on 01473 271272:

Problem	Cause	Possible Solution
Machine doesn't start	Machine not plugged in	Plug in machine
	Defective socket	Try another socket
	Fuse has blown	Replace fuse. Switch off other machines
	Defective extension cord	Try without the extension cord
Fluctuating pressure	Pump sucking air	Check that hoses and connections are airtight.
	Valves dirty, worn out or stuck	Clean and replace or refer to local distributor
	Pump seals worn out	Clean and replace or refer to local distributor
Machine stops	Incorrect mains voltage	Check that the mains voltage corresponds to specification on the model tag
	Thermal sensor activated	Leave the washer for 5 minutes to cool down
	Nozzle partially blocked	Clean the nozzle
Machine pulsating	Air in inlet hose	Allow machine to run with open trigger until regular working pressure resumes
	Inadequate supply of mains water	Check that the water supply corresponds to specifications required NOTE: Avoid using long, thin hoses (min. 1/2")
	Nozzle partially blocked	Clean the nozzle
	Water filter blocked	Clean the filter
	Hose kinked	Straighten out hose
Machine starts, but no water comes out	Pump/hoses or accessory frozen	Wait for pump/hoses or accessory to thaw
	No water supply	Connect inlet water.
	Water filter blocked	Clean the filter
	Nozzle blocked	Clean the nozzle

Model:	EW6140 AQUAROVER 140
Voltage:	220-240V ~
Frequency:	50Hz
Power (W):	1800
Protection Class:	II
IP Rating:	IPX5
Maximum Pressure (Bar):	140
Maximum flow rate (L/min):	7.8
Noise Level (dB):	92
Pump type:	Aluminium
Auto-stop system:	Yes
Self-priming:	Yes
Hose material:	PVC
Filter type:	PP
Product dimensions (mm):	H:696 x W:327 x D:351
Product weight:	11 kg

Fuse Replacement (Class II)

Remove the fuse cover with a small flat head screw driver. Take out the fuse and replace with a new fuse of the same Amp. Replace the fuse cover and push back into place.



Disposal Information

The European Directive 2012/19/EU on Waste Electrical and Electronic Equipment (WEEE), requires that old household electrical appliances must not be disposed of in normal unsorted municipal waste.

Old appliances must be collected separately in order to optimise the recovery and recycling of the materials they contain and reduce the impact on human health and the environment.

The crossed out "wheeled bin" symbol on the product reminds you of your obligation, that when you dispose of the appliance it must be separately collected. Consumers should contact their local authority or retailer for information concerning the correct disposal of their old appliance.





Ewbank Warranty Terms & Conditions

This product is guaranteed for a period of 24 months as standard from the date of purchase against mechanical and electrical defects.

To qualify for the warranty, the product must be used for domestic household use only and in accordance with the instructions in the user manual. Any misuse of the product will result in the warranty being void.

The warranty does not cover accidental damage, misuse, neglect, tampering or incorrect adjustment or installation.

The warranty will be rendered invalid if the product is resold, has had its serial number removed (or has an invalid serial number), or if an unauthorised person has carried out any repairs or alterations.

The warranty does not cover accessories or consumable parts that require replacement under normal use. This includes shelving, dials, filters, belts and trays etc.

In the unlikely event of a breakdown please refer to the Troubleshooting guide in your user manual and check all plugs, fuses and the electricity supply.

If you still require assistance please contact our Customer Service department on **01473 271 272** or write to us at the following address:

**Customer Service Department
Ewbank, 38 Bluestem Road,
Ipswich, Suffolk, IP3 9RR**

Please quote the Product Code and the PO Number on the rating label and give details of the exact fault. We will then decide whether to repair or replace the item.

Before we arrange the repair or replacement you will be required to return a copy of your proof of purchase. Please retain your original.

If an item is replaced within the agreed warranty period, the warranty for the replacement item will be calculated from the purchase date of the original.

In the event that the product is inspected and no fault is found or the product is not within the warranty period you will be charged for the repair and any carriage costs.



Your Guarantee

This product is covered by a 2 year guarantee.
This does not cover normal wear and tear or abuse.
For guarantee purposes, please retain your original receipt as proof of purchase.
This guarantee does not affect your statutory rights.
For spares, service and further information please contact;
Ewbank, 38 Bluestem Road, Ipswich, Suffolk, IP3 9RR
EU: Castle Electrical Factors Ltd., Dundalk, A91 KA9R, IR
Tel: 01473 271 272

Disclaimer: Ewbank operate a policy of continual improvement and development.
We therefore reserve the right to change/alter the specification and appearance of our appliances without prior notice.
All diagrams and images shown in this manual are for illustration purposes only.