


TROUBLESHOOTING GUIDE: CLEANING THE SPONGE DUST CHAMBER FILTER ON THE EWBANK AIRSTORM 1



The sponge dust chamber filter is located on the top of the dust container, and can be accessed by the pulling off the sponge dust chamber filter cover (fig.1 and 2).

Once the sponge dust chamber filter cover has been removed from the appliance, you can then remove the sponge dust chamber filter from the cover by twisting and unlocking it (fig.3).



Once the sponge dust chamber filter has been removed, it then needs to be cleaned to ensure it operates effectively and to prevent poor suction performance.

After several uses of the vacuum cleaner there will be dirt build up in the sponge filter (fig.4). **The more dirt that is left to build up in the sponge dust chamber filter, the worse the suction performance will get. It is therefore critical to ensure ongoing maintenance of the sponge dust chamber filter to keep it clean.** To do this, rinse the sponge dust chamber filter under the tap (can be either cold or warm water) to remove as much dirt as possible. You will know that it's clean when you can see the blue colour of the sponge return (fig.5).

The sponge dust chamber filter then needs to be left to completely dry before being reinstalled back into the vacuum cleaner. To dry the filter leave it in a warm place such as an airing cupboard or on top of a radiator. **Please note that if the filter is not completely dry when it is reinstalled this can lead to damage being caused to the vacuum cleaner.**